



Shoe and Spike Cleaner - Stiff Brush

RP549



Details

R&R Shoe and Spike Cleaners remove dirt and debris from shoes and spikes. This brush style lets you conveniently clean both the side and bottom of your shoes or boots. Bolt it down on the floor for easy access. Less aggressive Medium brushes are also available for "Spikeless" shoes. Constructed from durable cast aluminum with replaceable high-impact resistant plastic brushes.

Specifications

Manufacturer	R&R Products
--------------	--------------

Replacement Parts

RP14104	Screw - Side Brush 8 x 1/2
RP548	Side Brush - Shoe Cleaner
RP550-1	Screw - 10-24 x 7/8 FlsI SS
RP554	Stiff Bottom Brush - Shoe Cleaner